


# XpressChef®

## Panini Press Accessories

Panini sandwiches toasted to perfection without a hood

- Non-stick cooking surface
- Height-adjustable upper grill plate
- Easy to clean
- Removable
- 2 available styles—for XpressChef® 3i (MRX) or 4i (MXP) High Speed Ventless Ovens



|            | Panini Press Accessory for XC 3i MRX Ovens   | Panini Press Accessory for XC 4i MXP Ovens  |
|------------|--|---|
| ITEM#      | <b>PRS10R</b><br><i>(pictured left)</i>  | <b>PRS10</b><br><i>(pictured above)</i>   |
| HIGHLIGHTS | <ul style="list-style-type: none"> <li>• 2 Adjustable upper grill plate height levels</li> <li>• Upper open grooved grill plate</li> <li>• Lower Reversible grill plate (grooved/solid)</li> </ul> | <ul style="list-style-type: none"> <li>• 3 Adjustable upper grill plate height levels</li> <li>• Upper and Lower Reversible grill plates (grooved/solid)</li> </ul> |

**ACP**  
INC.  
Accelerated Cooking Products